

Corner Shower Rod Installation Help

1. Remove old rod and flanges from wall. Patch any existing holes from old hardware that will be exposed.
2. Accurately measure needed length of each piece of curtain rod. The rod ends can be cut down at the wall end if needed. Use a tube cutter to remove excess length. Mounting flanges will cover rod ends.
3. Place flanges on wall and mark holes with pencil.
4. Place 1" loop on to the rod.
5. Put the two rod sections together. Then place the end flanges onto shower rod.
6. Tighten setscrews on both flanges at the end of the rod.
7. Cut ceiling support to desired length if needed.
8. Place ceiling support into 1" loop and tighten setscrew. Then place the ceiling rod into the flange and tighten setscrew.
9. Screw the rod with flanges to the wall at marked location. Then screw the ceiling flange to the ceiling.