

Neo Angle Shower Rod Installation Help

1. Remove old rod and brackets from wall. Patch any existing holes from old hardware that will be exposed.
2. Measure distance between walls where shower curtain rod will mount. The rod ends can be cut down if needed. Cut the rod ends if a shorter rod is needed. Use a tube cutter to remove excess length. Mounting brackets will cover rod ends.
3. Place brackets on wall and mark holes with pencil.
4. Place 1" loop on to the rod. Then place existing brackets onto shower rod.
5. Tighten setscrews on both brackets at the end of the rod.
6. Cut ceiling support to desired length if needed.
7. Place ceiling support into 1" loop and tighten setscrew. Then place the ceiling rod into the flange and tighten setscrew.
8. Screw the rod w/ flange's to the wall at marked location. Then screw the ceiling flange to the ceiling.