



STILES EXPOSED PIPE SHOWER

INSTALLATION INSTRUCTIONS

Before installing, read entire Stiles Exposed Pipe Shower Installation Instructions. Observe all local building and safety codes.

For the following installation instructions it is assumed that the water supply lines have been installed in the desired location behind the finished wall and are accessible for shower installation.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your shower, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Smooth Jaw Wrench
Drill
Teflon Tape

Adjustable Wrench
Tape Measure
Soft Cloth

Silicone Thread Sealant
Level

IMPORTANT INFORMATION

- Install water supply lines in accordance with this manual.
- A floor drain should be installed in the shower location.
- Install the shower after construction is complete to avoid erosion or damage to the fixture by paint or chemicals.
- Wrap the pipe threads with Teflon tape prior to installation.
- To avoid damage to the shower, wrap a soft cloth around the pipe and shower head to before tightening with wrench.
- After installation, turn on the water supply and open the faucet valves. Check for any leaks and verify that the hot and cold supplies are working correctly. Let the water flow through the riser pipe and shower hose for approximately 30 seconds to clear out debris and dirt
- If leakage occurs, tighten connections with your adjustable wrench as necessary. If problems persist, contact Customer Service at 1-866-855-2284.



INSTALLATION INSTRUCTIONS

1. As specified in diagram, attach the shower base to the hot and cold water supply pipes in the wall.
2. Wrap the S-connectors with Teflon tape, and thread the connectors onto the supply pipes. Tighten with your adjustable wrench.
3. Use a level to verify the connectors are aligned properly. Adjust as necessary.
4. Thread the inner rings onto the S-connectors, keeping the threaded portion facing outward. Place the escutcheons on the inner rings with the horn mouth facing inward, and push them against the wall.
5. Attach the connecting nuts to the S-connector, and tighten.
6. Attach the connecting rod to the middle shower riser. Hold the mounting bracket in place in the desired mounting location.
7. Attach the middle shower riser to the shower body. Use a level to verify that the shower riser is in the proper location. When all pieces are properly aligned, mark the location of the mounting bracket on the wall.
8. Remove the middle shower riser, and drill two Ø8 holes at the locations marked in the previous step. Insert the wall anchors. Attach the mounting bracket to the wall with mounting screws. Attach the escutcheon to the mounting bracket.
9. Attach the shower support and the middle shower riser. Connect the bottom of the riser to the shower body and the top of the riser to the mounting bracket. Tighten the M6 screw to secure.
10. Thread the shower head onto the shower support. Tighten the locking nut and shower head to secure.
11. Connect the hand shower and shower hose.

