



CABINET HINGE

BEFORE INSTALLING

Read entire installation instructions below. Observe all local building and safety codes.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your cabinet hinge, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the hinge or cabinet, or for personal injury during installation.

TOOLS AND MATERIALS:



Pencil



Safety Glasses



Level



Drill



Tape Measure



Screwdriver

CABINET DOOR INSTALLATION

Below are general instructions for hanging cabinet doors; these apply regardless of hinge type. Following these guidelines ensures that cabinet doors are hung uniformly and fit properly into the openings.

1. Attach upper hinges to cabinet doors. Measuring from the top of the cabinet door, mark the position of the upper hinge on the door. This is typically about 3" from the top of the door. Mark the screw holes for the hinge and drill pilot holes. Use a screwdriver to secure the upper hinge to the door. Repeat for all other cabinet doors.

2. Attach lower hinges to cabinet doors. Measuring from the bottom of the cabinet door, mark the position of the lower hinge on the door. This should be the same measurement you used in step 1 and is typically about 3" from the bottom of the door. Mark the screw holes for the hinge and drill pilot holes. Use a screwdriver to secure the lower hinge to the door. Repeat for all other cabinet doors.

3. Mark the placement of the upper hinges on cabinets. Position a cabinet door against the cabinet to determine the ideal location of the door, considering both vertical and horizontal positioning and the mechanics of the hinge. The doors should end up perfectly centered over the openings of the cabinet. Use a pencil to make an "X" mark on the face of the cabinet at the exact location of the top screw of the upper hinge. Measure the horizontal and vertical distances of the "X" from the nearest top corner of the cabinet opening. Use these measurements to draw "X" marks for the other cabinets.

4. Attach cabinet door to cabinet. Drill a pilot hole for the top hole of the upper hinge. This pilot hole will be on the "X" mark. At this point, have someone hold the cabinet door in place while you continue to hang the cabinet door. Set this top screw with a screwdriver. Mark the position of lower screw of the bottom hinge on the cabinet, and drill that pilot hole. Set the bottom screw with a screwdriver.

5. Test and secure cabinet door. After completing step 5, the cabinet door that is attached to the face of the cabinet by only two screws. These screws will hold the door in place while you check how the door opens and closes. If everything appears functional, then mark the rest of the screw holes for the upper and lower hinges, drill pilot holes, and set the remaining screws.