



CREMONE BOLT

BEFORE INSTALLING

Read the installation instructions below. Observe all local building and safety codes.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your cremone bolt contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the bolt or door, or for personal injury during installation.

TOOLS AND MATERIALS:



Marker



Level



Drill



Hacksaw



Chisel

FLUSH-MOUNT INSTALLATION

1. Turn the cremone bolt handle (A) until the cremone mechanism is fully extended.
2. Assemble the cremone bolt by hooking the rods onto the cremone mechanism.
3. Hold the bolt together and place it in the desired mounting location on the face of your door or window.
Note: The flat side of the rods should be against the installation surface.
4. Mark the locations of the mounting holes in the bolt handle.
5. Determine the appropriate bolt rod length. The rods should extend 1/2" past the edge of the door. Trim the rods with a hacksaw as necessary.
6. Set the bolt aside and drill mounting holes in the locations marked in step 4.
7. Attach the bolt assembly (handle, and rods) to the installation surface with the flat face of the rods against the surface.
8. Holding the rods in place, attach the upper and lower mid-point guides (B) to the installation surface. Use a level to make sure that the rods are properly aligned. At this point, the bolt assembly is self-supported.
9. Attach the upper and lower end guides (C), allowing enough room for the end socket strikes.
10. Attach the end socket strikes (D) to the face of the trim above and below the door or window.

Refer to Figure 1 on page 2.



RECESSED INSTALLATION

1. Turn the cremone bolt handle (A) until the cremone mechanism is fully extended.
2. Assemble the cremone bolt by hooking the rods onto the cremone mechanism.
3. Hold the bolt together and place it in the desired mounting location on the face of your door or window.

Note: The flat side of the rods should be against the installation surface.

4. Mark the locations of the mounting holes in the bolthandle.
5. Determine the appropriate bolt rod length. The rods should extend 1/2" into the door jam. Trim the rods with a hacksaw as necessary.
6. Set the bolt aside and drill mounting holes in the locations marked in step 4.

7. Attach the bolt assembly (handle, and rods) to the installation surface with the flat face of the rods against the surface.

8. Holding the rods in place, attach the upper and lower mid-point guides (B) to the installation surface. Use a level to make sure that the rods are properly aligned. At this point, the bolt assembly is self-supported.

9. Attach the upper and lower end guides (C).

10. Close the door or window and mark the locations of the strike plates (E) on the door frame. Drill holes 1/2" deep for the bolt rods. Use a chisel to create a shallow recess around the holes so that the strike plates will be flush with the frame. Attach the strike plates to the frame.

Figure 1

