



# SHUTTER DOG

## BEFORE INSTALLING

Read entire shutter dog installation Instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the wall have been completed.

## INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your shutter dog contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the shutter or wall, or for personal injury during installation.

## TOOLS AND MATERIALS:



Drill



Tape Measure



Pencil



Hammer



Wrench



Safety Glasses



Socket Wrench



C-Clip



Anchor bolt



Masonry Anchors

## IMPORTANT INFORMATION

Be sure to wear protective eye wear when drilling.

## INSTALLATION

### 1. Determine the position of the shutter dog:

- Assemble the shutter dog and the lag bolt. **Note: Use an anchor bolt if installing on a brick wall.**
- With the shutter open, position the shutter dog against the house under the shutter so that the bolt is the desired distance in from the shutter's outer edge (typically between 2" and 4") and 1" below the bottom edge.
- Check that the shutter dog has enough contact with the shutter to hold it open. Then rotate the shutter dog 90 degrees and verify that the shutter has enough clearance to swing closed.
- Once you are satisfied with the shutter dog's position, mark the bolt's location on the house.

### 2. Drill bolt hole.

- If mounting to brick, drill the hole in the wall at the mark with a masonry drill bit. The hole should be the same diameter as the anchor you are using. Tap a masonry anchor into the hole with a hammer.
- If mounting to wood, use a drill bit for wood that is slightly smaller than the lag bolt.

### 3. Affix shutter dog to wall.

- If mounting to brick, thread the anchor bolt into the masonry anchor. Tighten the bolt with a socket wrench until the back of the shutter dog touches the shutter.
- If mounting to wood, thread the lag bolt into the hole with the socket wrench until the back of the shutter dog touches the shutter.
- If desired, slide a C-clip over the back of the shutter dog to secure the shutter dog against the head of the lag bolt or the masonry anchor bolt.

### 4. Repeat the process for each shutter dog.