



STAIR CARPET ROD

BEFORE INSTALLING

Read entire stair carpet rod installation instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the stairs have been completed.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the stairs or wall, for personal injury during installation.

TOOLS AND MATERIALS:



Drill



Screwdriver



Pencil

IMPORTANT INFORMATION

Be sure to wear protective eye wear when drilling.

INSTALLATION

1. **Lay the carpet.** Lay anti-skid rug padding and the carpet on the staircase. Ensure that you start the process from the top stair and that the carpet is centered on the staircase.
2. **Drill holes.** Lay the carpet rod in place on the top step and place the mounting brackets on either end. Make sure the rod is centered on the carpet. Use a pencil to mark the mounting bracket screw holes on the stair step and riser. Set the brackets aside and drill 1/16" pilot holes into the wood at each mark.
3. **Mount brackets.** Attach the mounting brackets to the stair step and riser with the screws provided. Place the stair rod into the crease between the step and riser and secure each end into the mounting bracket.
4. **Repeat the procedure for each stair on the staircase.**

