

Disposer flange fits the following garbage disposal models:

Caloric – WUR200, WUR210, WUR400

Eliminator – D3000, D-30001, D-5000, DF-5500, D-7501

Frigidaire – FD3000D, FD3001D, FD5000D, FD5500D, FD5501D, FD7501D

GE – GFC1000G, GFC197G, GFC232G, GFC240G, GFC241G, GFC440G, GFC610G

Gibson – GD30V, GD50V, GD55V

Kelvinator – KF30F, KF50F, KF55F

Magic Chef – L10C-C, L30C, L50C, L50C-C

Mr. Rooter – 383, 883, 983

Modern Maid – WXD750A

M. Ward – 21518, 21583, 21540, 21542

PHCC – 194, 294, 394, 994, 1094

Sinkmaster - 401, 501, 701, 801, 901PC, 450, 550, 850, 950, 1050, 1500, 2100, 2500, 3000

Tappan/O'Keefe - 51-1135, 51-2135, 51-3125, 51-4125, 51-5345

Whirlaway - 891, 191, 191AP, 191PC, 291, 291AP, 291PC, 391, 391PC, 591, 591PC, 991, 991PC 1091

White-Westinghouse - WD300J, WD301J, WD500J, WD550J, WD551J, WDF750J