



STAINLESS STEEL VESSEL SINK INSTALLATION

BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures and plumbing. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing, vanity cabinet, sink, counter top, or personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the sink for damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For the following instructions, it is assumed that the vanity and countertop are already in place.

TOOLS AND MATERIALS:



Silicone Sealant
(100% Neutral
Cure)




Damp Cloth




STAINLESS STEEL VESSEL SINK INSTALLATION

Installation


1. Carefully place your vessel sink upside down on the counter top. Apply a generous amount of silicone sealant to the base of the sink where it will rest on the counter.




2. Turn the sink right-side-up and position over the drain hole. Set the sink in place, and press firmly to secure.



3. If desired, apply a continuous bead of silicone sealant around the perimeter of the sink base for additional stability.



4. Remove any excess sealant with a damp cloth to complete installation.





STAINLESS STEEL VESSEL SINK INSTALLATION

5. Proceed to the installation of the sink drain. Refer to the drain's installation instructions for guidance.



6. Allow the sealant to fully dry for 24 hours.



Cleaning and Maintenance

It is recommended that you use a cleaner or polish that is designed specifically for stainless steel products. You may use a gentle soap, such as dish washing liquid and warm water. Acidic cleaners, such as lemon juice, should be avoided. We recommend the use of a soft sponge or microfiber washcloth. Do not use any abrasive cleaning pads or materials. Rinse with warm water and dry with a clean, soft cloth.

Minor scratches can be removed using a scratch remover designed specifically for stainless steel or metals. Refer to the directions for the product being used, as each scratch remover will have its own step-by-step procedure. For deeper scratches, wet sanding may be necessary using 600-grit (coarse) or 1000-grit (fine) sandpaper attached to a rubber sanding block. After sanding, use a stainless steel polish to restore shine if desired.